

Alesis FireWire Mac Driver and Software

September 2009

A. FIRST STEP: READ THIS DOCUMENT

Driver 3.4.2.6300 includes support for Mac OS 10.6 "Snow Leopard" (32-bit kernel). Your Mac must be running OS 10.4, 10.5 or 10.6. Both PowerPC and Intel Macs are supported.

FOR TROUBLE-FREE RESULTS, DO NOT CONNECT YOUR ALESIS FIREWIRE DEVICE TO YOUR COMPUTER UNTIL INSTRUCTED TO DO SO.

B. SECOND STEP: INSTALL THE MAC DRIVER AND HARDWARE DIRECT MONITORING APPLICATION

1. Double click *AlesisFirewire.dmg*. Then, open the drive that appears on your desktop.
2. Run the *AlesisFirewireUninstaller* program to remove any prior Alesis Firewire audio drivers on your system. *(You can skip this step if you have never installed an Alesis Firewire device on your computer.)*
3. Run *AlesisFirewire-3.4.2.6300.pkg* to install the current driver.
4. (IO|14 or IO|26 only) Run *AlesisHDM_1_28.pkg* from *AlesisHDM1_28.pkg.zip* to install the Hardware Direct Monitoring application. Any prior installation will be automatically overwritten.

Your new software and drivers are now installed and ready for use. Attach your Alesis Firewire device to your computer now.

C. IN CASE OF DIFFICULTY

Alesis's customer support team is available for further troubleshooting and consultation. Call (401) 658-5760.

Thank you for using Alesis products. Best of luck to you in all your creative endeavors!

The Alesis Team