



MasterControl Installation Instructions (Mac)

December 16, 2008

1. READ THIS DOCUMENT

NOTE: THE MASTERCONTROL DRIVERS REQUIRE MAC OS X 10.4 OR HIGHER

Your Mac must be running OS X 10.4 or OS X 10.5.

Both PowerPC and Intel Macs are supported.

FOR TROUBLE-FREE RESULTS, DO NOT CONNECT YOUR MASTERCONTROL TO YOUR COMPUTER UNTIL INDICATED AFTER STEP 3.

2. REMOVE ANY OLDER DRIVERS

Do not attach your MasterControl to your computer yet.

Double click *2--Alesis_Firewire_3_3_3_3355.dmg*. Then, open the drive that appears on your desktop. Run the *AlesisFirewireCleaner* program to remove any prior Alesis Firewire audio drivers on your system.

(You can skip this step if you have never installed an Alesis Firewire device on your computer.)

3. INSTALL THE 3.3.3.3355 (CURRENT) DRIVER

Run *AlesisFirewire-3.3.3.3355.pkg* to install the current driver.

Your new drivers have been installed and are ready for use. Attach your MasterControl to your computer now.

4. IN CASE OF DIFFICULTY

Alesis's customer support team is available in case of any difficulties. Call (401) 658-5760 during regular, East Coast business hours.

5. FEEDBACK ON THE DRIVER

Alesis welcomes feedback on this beta driver release. You may report any issues or impressions with this beta driver to Alesis via email at firewire@alesis.com.

Thank you for using Alesis products. Best of luck to you in all your creative endeavors!

The Alesis Team